



FITTING INSTRUCTIONS

The packaging includes: **the needle 5,50 mt** of waxed thread.

Necessary quantity of thread:

- a) **2 Spokes Steering wheel:** 3 mt of thread for the upper part - 2 mt. of thread for the lower part.
- b) **3 Spokes Steering wheel:** 2 mt. of thread for the upper part - 1 mt. of thread for the right lower part - 1 mt. of thread for the left lower part.
- c) **4 Spokes Steering wheel:** 2 mt. of thread for the upper part - 1 mt. of thread for the central lower part - 0,5 mt. of thread for the left lower part.

- 1 Wrap and fit the cover steering wheel on the ring taking care of the spokes positioning in order to let them exactly correspond to those of the steering wheel to cover **(Picture No. 1)**.
- 2 When the steering wheel borders suit perfectly with the internal median line of the steering wheel ring, lace the lower edges and then the upper ones fixing them with the pression buttons. **(Picture No. 2)**
- 3 Insert the thread through the eye of the needle and make a double knot at its end **(Picture No. 3)**.
- 4 Start the sewing from one of the lowest sections of the steering wheel. Insert the needle along with the thread from the inner side and in the hole indicated with "X" **(Picture No. 3)**.
Pass the needle through the external and then string it always externally in the first hole on the front side of the steering wheel cover **(Picture No. 4)**. Repeat the process twice as shown in **(Picture No. 5)**.
- 5 Enter in with the needle in the internal side of the hole indicated with "Y" **(Picture No. 5)** and continue with the sewing **(Picture No. 6)**
- 6 Getting out from the last back hole, keeping the thread tight, wrap it twice up on the needle **(Picture No. 7)**. String the needle again, wrap from the thread, in the front hole and get out from the back one **(Picture No 8)**. Keep tight in order to have a knot getting inside the leather **(Picture No 9)**

ISOTTA Steering Wheel Cover suits perfectly.